

Update: **Cavex Outline Impression Paste**

We'd like to inform you about a **small change** in the product's characteristics. One of the unique raw materials used in Outline is no longer available, which meant we had to slightly **adjust the formula**.

The quality remains excellent, but you may notice **some variation in the setting times**, both in the mouth and during final hardening. In fact, Cavex has updated the maximum final setting time from **15 to 20 minutes**.

Of course, we're doing our best to keep setting times short. But if you experience longer setting, we have two simple tips that can help:

Let's start by reviewing the standard working time:

- **Mixing** takes about **30 to 45 seconds**
- **Intraoral setting** varies between **3 to 6 minutes from the start**
- **Final hardness** is reached between **13 to 20 minutes from the start of mixing**

If you'd like to speed things up, here are two workarounds:

1. **Wait 1 to 2 minutes after mixing before placing the tray or denture in the mouth**—this helps reduce the intraoral setting time.
2. **After removal, place the impression in a container of lukewarm water at 40°C or 104°F for 2 to 3 minutes**—this will significantly accelerate the final hardening.

We hope these tips make it even easier for you to continue working confidently with **Cavex Outline**.